

Gesamthubhöhe = Hubhöhe + ca. 1,2m Aufbauniveau
Overall height = vertical outreach + approx. 1,2m installation height
 Hauteur totale = portee verticale + env. 1,2m hauteur de pose

